



PerfectClean

Calcium Cleaner Gel

Application:	Gel for removing persistent lime surfaces.	
Procedure to use:	Wash rollers with a roller wash, after that apply PerfectClean Calcium Cleaner Gel on the roller, with the roller running slowly. The dissolving process will be completed after a few minutes, at the end wash off with water. In case of persistent deposits repeat the procedure.	
Product parameters:	Form:	liquid, viscous
	Specific gravity:	~ 1,0 g/ml
	Flash point:	NA
	VOC content:	15% by 20°C
Storage conditions:	Store at room temperature conditions.	
Shelf life:	In unopened, original packaging, 5 years from manufacturing date	
Packaging:	1ltr bottle	

The information provided in this technical data sheet is to inform our customers. A successful application depends on a variety of different factors. Therefore the advice given in this technical data sheet cannot be used as basis for claims. Our recommendation is where possible to perform tests before entering production runs. We reserve the rights to change product characteristics because of technical progress, amendment of applicable law and mandatory production related needs.